

# ENGINE LUBRICATION & COOLING SYSTEMS

## SECTION LC

GI  
MA  
EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

## CONTENTS

<b>KA24DE</b>
<b>ENGINE LUBRICATION SYSTEM</b> .....3
Precautions .....3
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)
"AIR BAG" AND "SEAT BELT PRE-TENSIONER".....3
LIQUID GASKET APPLICATION PROCEDURE.....3
Preparation .....4
SPECIAL SERVICE TOOLS .....4
Lubrication Circuit.....5
Oil Pressure Check.....6
Oil Pump.....6
REMOVAL AND INSTALLATION.....6
REGULATOR VALVE INSPECTION .....7
OIL FILTER .....7
OIL PUMP INSPECTION .....7
Service Data and Specifications (SDS).....8
OIL PRESSURE CHECK .....8
REGULATOR VALVE .....8
OIL PUMP .....8
<b>ENGINE COOLING SYSTEM</b> .....9
Precautions .....9
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)
"AIR BAG" AND "SEAT BELT PRE-TENSIONER".....9
LIQUID GASKET APPLICATION PROCEDURE.....9
Preparation .....10
SPECIAL SERVICE TOOLS .....10
Cooling Circuit .....10
System Check.....11
CHECKING COOLING SYSTEM HOSES.....11
CHECKING RADIATOR.....11
CHECKING COOLING SYSTEM FOR LEAKS.....11
CHECKING RADIATOR CAP .....12
Water Pump.....12
REMOVAL.....12
INSPECTION.....12
INSTALLATION.....13
Thermostat.....13
REMOVAL.....13
INSPECTION.....13
INSTALLATION.....13

Radiator .....14
REMOVAL AND INSTALLATION.....14
COMPONENTS .....15
INSPECTION.....15
Cooling Fan (Crankshaft driven) .....16
REMOVAL AND INSTALLATION.....16
INSPECTION.....16
Refilling Engine Coolant .....16
Overheating Cause Analysis .....17
Service Data and Specifications (SDS).....18
THERMOSTAT .....18
RADIATOR.....18

<b>VG33E AND VG33ER</b>
<b>ENGINE LUBRICATION SYSTEM</b> .....19
Precautions .....19
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)
"AIR BAG" AND "SEAT BELT PRE-TENSIONER".....19
LIQUID GASKET APPLICATION PROCEDURE.....19
Preparation .....20
SPECIAL SERVICE TOOLS .....20
Lubrication Circuit.....20
Oil Pressure Check.....21
Oil Pump.....21
REMOVAL AND INSTALLATION.....21
DISASSEMBLY AND ASSEMBLY.....22
INSPECTION.....23
REGULATOR VALVE INSPECTION .....23
OIL FILTER .....23
OIL FILTER BRACKET .....24
Service Data and Specifications (SDS).....25
OIL PRESSURE CHECK .....25
REGULATOR VALVE .....25
OIL PUMP .....25
<b>ENGINE COOLING SYSTEM</b> .....26
Precautions .....26
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)
"AIR BAG" AND "SEAT BELT PRE-TENSIONER".....26
LIQUID GASKET APPLICATION PROCEDURE.....26
Preparation .....27

# CONTENTS (Cont'd)

SPECIAL SERVICE TOOLS .....	27	Radiator .....	32
Cooling Circuit .....	27	REMOVAL AND INSTALLATION.....	32
System Check.....	27	COMPONENTS .....	33
CHECKING COOLING SYSTEM HOSES.....	27	INSPECTION.....	33
CHECKING RADIATOR CAP .....	28	Cooling Fan (Crankshaft driven) .....	34
CHECKING RADIATOR.....	28	REMOVAL AND INSTALLATION.....	34
CHECKING COOLING SYSTEM FOR LEAKS.....	29	INSPECTION.....	34
Water Pump.....	29	Refilling Engine Coolant .....	35
REMOVAL.....	29	Overheating Cause Analysis .....	35
INSPECTION.....	30	Service Data and Specifications (SDS).....	36
INSTALLATION.....	30	THERMOSTAT .....	36
Thermostat.....	31	RADIATOR.....	36
REMOVAL.....	31		
INSPECTION.....	31		
INSTALLATION.....	32		

## Precautions



### SUPPLEMENTAL RESTRAINT SYSTEM (SRS) "AIR BAG" AND "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, crash zone sensor, seat belt buckle switches, warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS** section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.



### LIQUID GASKET APPLICATION PROCEDURE

1. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Silicone RTV or equivalent. Refer to **GI-50**, "Recommended Chemical Products and Sealants".)
  - For oil pan, be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
  - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## Preparation

### SPECIAL SERVICE TOOLS



=NGLC0068

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
(J34301-C) Oil pressure gauge set 1: (J34301-1) Oil pressure gauge 2: (J34301-2) Hoses 3: (J34298) Adapter 4: (J34282-1) Adapter 5: (790-301-1230-A) 60° adapter 6: (J34301-15) Square socket	 <p style="text-align: left; margin-top: 10px;">AAT896</p>	Measuring oil pressure <b>Maximum measuring range:</b> <b>1,379 kPa (14 kg/cm<sup>2</sup>, 200 psi)</b>
WS39930000 ( — ) Tube presser	 <p style="text-align: left; margin-top: 10px;">NT052</p>	Pressing the tube of liquid gasket
KV10115801 (J38956) Oil filter wrench	 <p style="text-align: left; margin-top: 5px;">14 faces, Inner span: 64.3 mm (2.531 in) (Face to opposite face)</p> <p style="text-align: left; margin-top: 10px;">NT362</p>	Removing and installing oil filter

## Lubrication Circuit

NGLC0069



1. Connecting rod
2. Connecting rod bearing
3. Main bearing
4. Oil filter
5. Oil strainer

6. Oil pump
7. Oil pan
8. Piston oil jet
9. Timing chain tensioner

10. Idler sprocket
11. Upper timing chain tensioner
12. Exhaust camshaft
13. Intake camshaft

GI

MA

EM

**LC**

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT


HA

WLC030

SC

EL

IDX



## Oil Pressure Check

### WARNING:

- Be careful not to burn yourself, as the engine and oil may be hot.
  - Put the shift lever in the Neutral "N" position.
1. Check oil level.
  2. Remove oil pressure switch.
  3. Install pressure gauge.
  4. Start engine and warm it up to normal operating temperature.
  5. Check oil pressure with engine running under no-load.

Unit: kPa (kg/cm<sup>2</sup>, psi)

Engine speed	Approximate discharge pressure
Idle speed	More than 78 (0.8, 11)
3,000 rpm	412 - 481 (4.2 - 4.9, 60 - 70)

- If difference is extreme, check oil passage and oil pump for oil leaks.


6. Install oil pressure switch with sealant.

: 12.25 – 17.15 N·m (1.3 – 1.7 kg·m, 9 – 12 ft·lb)


ALC059

## Oil Pump


### REMOVAL AND INSTALLATION



SLC945-A




- Always replace with new oil seal and gasket.
- When removing oil pump, turn crankshaft so that No. 1 piston is at TDC on its compression stroke.
- When installing oil pump, apply engine oil to gears, then align punch mark on drive spindle and oil hole on oil pump.



## REGULATOR VALVE INSPECTION

NGLC0072

1. Visually inspect components for wear and damage.
  2. Check oil pressure regulator valve sliding surface and valve spring.
  3. Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.
- Replace regulator valve set or oil pump assembly, if damaged.




## OIL FILTER

NGLC0073

The oil filter is a small, full-flow cartridge type and is provided with a relief valve.

- Use Tool KV10115801 (J38956) for removing oil filter.



## OIL PUMP INSPECTION

NGLC0074


Using a feeler gauge, check the following clearances.

**Standard clearance:**

Unit: mm (in)

Rotor tip clearance 1	Less than 0.12 (0.0047)
Outer rotor to body clearance 2	0.15 - 0.21 (0.0059 - 0.0083)
Side clearance (with gasket) 3	0.04 - 0.100 (0.0016 - 0.0039)

- If the tip clearance (1) exceeds the limit, replace rotor set.
- If body to rotor clearances (2, 3) exceed the limit, replace oil pump assembly.



# ENGINE LUBRICATION SYSTEM

KA24DE

Service Data and Specifications (SDS)

## Service Data and Specifications (SDS)

### OIL PRESSURE CHECK

Unit: kPa (kg/cm<sup>2</sup>, psi)  
NGLC0075

Engine speed	Approximate discharge pressure
Idle speed	More than 78 (0.8 , 11)
3,000 rpm	412 - 481 (4.2 - 4.9, 60 - 70)

### REGULATOR VALVE

Unit: mm (in)  
NGLC0131

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)
---	---------------------------------

### OIL PUMP

Unit: mm (in)  
NGLC0076

Rotor tip clearance	Less than 0.12 (0.0047)
Outer rotor to body clearance	0.15 - 0.21 (0.0059 - 0.0083)
Side clearance (with gasket)	0.04 - 0.100 (0.0016 - 0.0039)

## Precautions



### SUPPLEMENTAL RESTRAINT SYSTEM (SRS) "AIR BAG" AND "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The Supplemental Restraint System consists of driver air bag modules (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, crash zone sensor, seat belt buckle switches, warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS** section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.



### LIQUID GASKET APPLICATION PROCEDURE

1. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Silicone RTV or equivalent. Refer to **GI-50**, "Recommended Chemical Products and Sealants".)
  - For oil pan, be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
  - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## Preparation

### SPECIAL SERVICE TOOLS


=NGLC0110

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
EG17650301 (J33984-A) Radiator cap tester adapter		Adapting radiator cap tester to radiator filler neck <b>a: 28 (1.10) dia.</b> <b>b: 31.4 (1.236) dia.</b> <b>c: 41.3 (1.626) dia.</b> Unit: mm (in)
WS39930000 ( — ) Tube presser		Pressing the tube of liquid gasket

## Cooling Circuit

NGLC0111



ALC117

## System Check

NGLC0112

### WARNING:

- Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.
- Wrap a thick cloth around the radiator cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the radiator cap by turning it all the way.

GI

MA

EM

## CHECKING COOLING SYSTEM HOSES

NGLC0112S01

Check hoses for the following:

- Improper attachment
- Leaks
- Cracks
- Damage
- Chafing
- Deterioration

LC

EC

FE

## CHECKING RADIATOR

NGLC0112S02

Check radiator for mud or clogging. If necessary, clean radiator as follows.

### CAUTION:

- Be careful not to bend or damage the radiator fins.
  - When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, radiator shroud and horns.
  - Tape the harness connectors to prevent water from entering.
1. Apply water by hose to the back side of the radiator core vertically downward.
  2. Apply water again to all radiator core surfaces once per minute.
  3. Stop washing when water coming out of the radiator flows clear.
  4. Blow air into the back side of radiator core vertically downward.
    - Use compressed air lower than 490 kPa (5 kg/cm<sup>2</sup>, 71 psi) and keep the air hose end more than 30 cm (11.8 in) away.
  5. Blow air again into all the radiator core surfaces once per minute until no water blows out and the core is dry.

CL

MT

AT

TF

PD


AX

SU

BR

ST

RS



## CHECKING COOLING SYSTEM FOR LEAKS

NGLC0112S03

To check for leakage, apply pressure to the cooling system with a radiator cap tester.

### Testing pressure:

157 kPa (1.6 kg/cm<sup>2</sup>, 23 psi)

### CAUTION:

Higher pressure than specified may cause radiator damage.

BT


HA

SC

EL

IDX

## System Check (Cont'd)

**CHECKING RADIATOR CAP**

NGLC0112S04


To check radiator cap, apply pressure to radiator cap with a radiator cap tester.

**Radiator cap relief pressure:****Standard**


78 - 98 kPa (0.8 - 1.0 kg/cm<sup>2</sup>, 11 - 14 psi)

**Limit**

59 kPa (0.6 kg/cm<sup>2</sup>, 9 psi)




Pull the negative pressure valve to open it. Check that it closes completely when released.

**Water Pump****REMOVAL**

NGLC0113


**CAUTION:**

- When removing water pump assembly, be careful not to get coolant on drive belts.
  - Water pump cannot be disassembled and should be replaced as a unit.
  - After installing water pump, connect hose and clamp securely. Check for leaks using radiator cap tester.
1. Drain coolant from engine. Refer to **MA-17**, "Changing Engine Coolant".
  2. Remove fan coupling with fan.
  3. Remove power steering pump drive belt, generator drive belt and A/C compressor drive belt.
  4. Remove water pump.

**INSPECTION**

NGLC0114

- Check body assembly for rust or corrosion.
- Check for rough operation due to excessive end play.



## INSTALLATION


NGLC0115

1. Use a scraper to remove liquid gasket from water pump.
  - Also remove traces of liquid gasket from mating surface of cylinder block.

GI

MA

EM

**LC**


2. Apply a continuous bead of liquid gasket to mating surface of water pump.
  - Use Genuine Silicone RTV or equivalent. Refer to *GI-50*, "Recommended Chemical Products and Sealants".

EC


When filling the radiator with coolant, refer to *MA-17*, "Changing Engine Coolant".

FE

When installing the drive belts, refer to *MA-16*, "Checking Drive Belts".

CL

MT



## Thermostat

### REMOVAL

NGLC0116


- Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.
1. Drain coolant from engine. Refer to *MA-17*, "Changing Engine Coolant".
  2. Remove air cleaner and air duct assembly.
  3. Remove water hose from water inlet housing.
  4. Remove water inlet housing, then take out thermostat.

AT

TF

PD

AX



## INSPECTION

NGLC0117

1. Check valve seating condition at normal room temperature. It should seat tightly.
2. Check valve opening temperature and valve lift.

SU


BR

Valve opening temperature	76.5°C (170°F)
Valve lift	More than 8 mm/90°C (0.31 in/194°F)

ST

3. Check if valve closes at 5°C (9°F) below valve opening temperature.

RS



## INSTALLATION

NGLC0118

1. Use a scraper to remove old liquid gasket from water inlet.
  - Also remove traces of liquid gasket from mating surface of front cover.
2. Apply a continuous bead of liquid gasket to mating surface of water inlet.
  - Use Genuine Silicone RTV or equivalent. Refer to *GI-50*, "Recommended Chemical Products and Sealants".

BT


HA

SC

EL

IDX

## Thermostat (Cont'd)



3. Install thermostat with jiggle valve or air bleeder at upper side.
  4. Install water inlet housing.
  5. Install water hose to water inlet housing.
  6. Install air cleaner and air duct assembly.
  7. Refill engine coolant. Refer to **MA-17**, "Changing Engine Coolant".
- **After installation, run engine for a few minutes and check for leaks.**


**Radiator****REMOVAL AND INSTALLATION**

NGLC0119

1. Remove under cover.
  2. Drain coolant from radiator. Refer to **MA-17**, "Changing Engine Coolant".
  3. Disconnect upper and lower radiator hoses.
  4. Remove air cleaner and air duct assembly.
  5. Remove lower radiator shroud.
  6. Remove radiator shroud.
  7. Disconnect coolant reservoir hose.
  8. Remove radiator.
  9. After replacing radiator, install all parts in reverse order of removal.
  10. Refill engine coolant. Refer to **MA-17**, "Changing Engine Coolant".
- **After installation, run engine for a few minutes, and check for leaks.**

## COMPONENTS

NGLC0120



GI

MA

EM

**LC**

EC

FE

CL


MT

AT

TF

PD

AX



### INSPECTION

NGLC0130


1. Apply pressure with Tool.  
**Specified pressure value:**  
**157 kPa (1.6 kg/cm<sup>2</sup>, 23 psi)**

SU

BR

ST

RS



2. Check for leakage.

BT


HA

SC

EL

IDX

## Cooling Fan (Crankshaft driven)




## Cooling Fan (Crankshaft driven)

## REMOVAL AND INSTALLATION

NGLC0121


- Do not release the drive belt tension by removing the fan/water pump pulley.
- Fan coupling cannot be disassembled and should be replaced as a unit. If front mark **F** is present, install fan so that side marked **F** faces the front.
- Install the drive belt only after the fan and fan coupling to water pump flange bolts/nuts have been properly torqued.
- Proper alignment of these components is essential. Improper alignment will cause them to wobble and may eventually cause the fan to separate from the water pump, causing extensive damage.



## INSPECTION

NGLC0122

Check fan coupling for rough operation, wobbling, oil leakage, or bent bimetal fins.



After assembly, verify the fan does not wobble or flap while the engine is running.

**WARNING:**

- When the engine is running, keep hands and clothing away from moving parts such as drive belts and fan.

## Refilling Engine Coolant

NGLC0123

For details on refilling the engine cooling system, refer to **MA-17**, "REFILLING ENGINE COOLANT".

# ENGINE COOLING SYSTEM

**KA24DE**

Overheating Cause Analysis

## Overheating Cause Analysis

=NGLC0125

		Symptom	Check items			
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	—	GI	
		Thermostat stuck closed	—		MA	
		Damaged fins	Dust contamination or paper clogging		—	EM
			Mechanical damage			LC
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)			
	Reduced air flow	Fan coupling does not operate	Fan and coupling	—	EC	
		High resistance to fan rotation			FE	
		Damaged fan blades				
	Damaged radiator shroud	—	Fan shroud	—	CL	
	Improper coolant mixture ratio	—	Coolant quality, viscosity	—	MT	
	Poor coolant quality	—		—		
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp	AT	
				Cracked hose		
			Water pump	Poor sealing	TF	
			Radiator cap	Loose	PD	
				Poor sealing		
			Radiator	O-ring for damage, deterioration or improper fitting	AX	
Cracked radiator tank		SU				
Cracked radiator core						
Reservoir tank	Cracked reservoir tank					
Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration	BR			
		Cylinder head gasket deterioration	ST			

# ENGINE COOLING SYSTEM

KA24DE

## Overheating Cause Analysis (Cont'd)

	Symptom		Check items		
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	Excessive payload	
				Driving in low gear for extended time	
				Driving at extremely high speed	
			Powertrain system malfunction	—	Installed improper size wheels and tires
					Dragging brakes
	Improper ignition timing				
	Blocked or restricted air flow	Blocked bumper	Blocked radiator grille	—	Installed car brassiere
					Mud contamination or paper clogging
				Blocked radiator	Dirty radiator
				Blocked condenser	Dirty condenser
Blockage in front of radiator				Installed large fog lamp	

## Service Data and Specifications (SDS)

### THERMOSTAT

NGLC0126

Valve opening temperature	76.5°C (170°F)
Valve lift	More than 8 mm/90°C (0.31 in/194°F)

### RADIATOR

Unit: kPa (kg/cm<sup>2</sup>, psi)  
NGLC0127

Cap relief pressure	Standard	78 - 98 (0.8 - 1.0, 11 - 14)
	Limit	59 (0.6, 9)
Leakage test pressure		157 (1.6, 23)

## Precautions



## SUPPLEMENTAL RESTRAINT SYSTEM (SRS) "AIR BAG" AND "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types collision. The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, crash zone sensor, seat belt buckle switches, warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS** section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.







## LIQUID GASKET APPLICATION PROCEDURE

1. Use a scraper to remove all traces of old liquid gasket from mating surface and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Silicone RTV or equivalent. Refer to **GI-50**, "Recommended Chemical Products and Sealants".)
  - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) diameter (for oil pan).
  - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) diameter (in areas except oil pan).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.


## Preparation



### SPECIAL SERVICE TOOLS

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here. =NGLC0002

Tool number (Kent-Moore No.) Tool name	Description	
ST25051001 (J25695-1) Oil pressure gauge		Measuring oil pressure <b>Maximum measuring range:</b> <b>2,452 kPa (25 kg/cm<sup>2</sup>, 356 psi)</b>
NT558		
ST25052000 (J25695-2) Hose		Adapting oil pressure gauge to cylinder block
NT559		
KV10115801 (J38956) Oil filter wrench		Removing and installing oil filter
NT362		
WS39930000 ( — ) Tube presser		Pressing the tube of liquid gasket
NT052		

## Lubrication Circuit

NGLC0003




## Oil Pressure Check

NGLC0004

### WARNING:

- Be careful not to burn yourself, as the engine and oil may be hot.
- Put the shift lever in the Neutral “N” position.

1. Check oil level.
2. Remove oil pressure switch.

3. Install pressure gauge.
4. Start engine and warm it up to normal operating temperature.
5. Check oil pressure with engine running under no-load.

Unit: kPa (kg/cm<sup>2</sup>, psi)

Engine speed	Approximate discharge pressure
Idle speed	More than 59 (0.6, 9)
2,000 rpm	412 - 451 (4.2 - 4.6, 60 - 65)

**If difference is extreme, check oil passage and oil pump for oil leaks.**

6. Install oil pressure switch with sealant.

: 12.25 - 17.15 N·m (1.3 - 1.7 kg-m, 9 - 12 ft-lb)

## Oil Pump


### REMOVAL AND INSTALLATION

NGLC0005






1. Drain engine oil.
2. Drain engine coolant from drain plug on radiator.
3. Remove air duct from mass air flow sensor to throttle body.
4. Remove cooling fan.
5. Remove radiator hoses (upper and lower) and fan shroud. Refer to “Radiator”, LC-32.
6. Remove drive belts. Refer to **MA-26**, “Checking Drive Belts”.
7. Remove crankshaft pulley and front upper and lower belt covers. Refer to **EM-82**, “TIMING BELT”.
8. Remove oil pan. Refer to **EM-79**, “OIL PAN”.
9. Remove oil strainer.
10. Remove oil pump assembly.

### DISASSEMBLY AND ASSEMBLY

NGLC0006



- Always replace with new oil seal and gasket.
- When installing oil pump, apply engine oil to inner and outer gears.
- Be sure that O-ring is properly installed.



### INSPECTION

NGLC0007

Using a feeler gauge, straightedge and micrometers, check the following clearances:

Unit: mm (in)

Body to outer rotor radial clearance 1	0.114 - 0.200 (0.0045 - 0.0079)
Inner rotor to outer rotor tip clearance 2	Below 0.18 (0.0071)
Body to inner rotor axial clearance 3	0.05 - 0.09 (0.0020 - 0.0035)
Body to outer rotor axial clearance 4	0.050 - 0.110 (0.0020 - 0.0043)
Inner rotor to brazed portion of housing clearance 5	0.045 - 0.091 (0.0018 - 0.0036)

- If the tip clearance (2) exceeds the limit, replace rotor set.
- If body to rotor clearances (1, 3, 4, 5) exceed the limit, replace oil pump body assembly.

### REGULATOR VALVE INSPECTION

NGLC0008

1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.

If damaged, replace regulator valve set or oil pump assembly.


### OIL FILTER

NGLC0009

The oil filter is a small, full-flow cartridge type and is provided with a relief valve.

- Use Tool KV10115801 (J38956) for removing oil filter.

Oil Pump (Cont'd)



### OIL FILTER BRACKET

NGLC0010

1. Remove oil filter.
2. Disconnect oil pressure switch and connector.
3. Remove oil filter bracket.

## Service Data and Specifications (SDS)

## OIL PRESSURE CHECK

Unit: kPa (kg/cm<sup>2</sup>, psi)<sup>=NGLC0011</sup>

Engine speed	Approximate discharge pressure
Idle speed	More than 59 (0.6, 9)
2,000 rpm	412 - 451 (4.2 - 4.6, 60 - 65)

## REGULATOR VALVE

Unit: mm (in)<sup>NGLC0012</sup>

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)
---	---------------------------------

## OIL PUMP

Unit: mm (in)<sup>NGLC0013</sup>

Body to outer rotor radial clearance	0.114 - 0.200 (0.0045 - 0.0079)
Inner rotor to outer rotor tip clearance	Below 0.18 (0.0071)
Body to inner rotor axial clearance	0.05 - 0.09 (0.0020 - 0.0035)
Body to outer rotor axial clearance	0.050 - 0.110 (0.0020 - 0.0043)
Inner rotor to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

## Precautions

**SUPPLEMENTAL RESTRAINT SYSTEM (SRS) “AIR BAG” AND “SEAT BELT PRE-TENSIONER”**



The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types collision. The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, crash zone sensor, seat belt buckle switches, warning lamp, wiring harness and spiral cable.

NGLC0135

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

**LIQUID GASKET APPLICATION PROCEDURE**



NGLC0014

1. Use a scraper to remove all traces of old liquid gasket from mating surface and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Silicone RTV or equivalent. Refer to **GI-50**, “Recommended Chemical Products and Sealants”.)
  - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) dia. (for oil pan).
  - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) dia. (in areas except oil pan).
3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.


## Preparation

### SPECIAL SERVICE TOOLS

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here. =NGLC0015

Tool number (Kent-Moore No.) Tool name	Description	
EG17650301 (J33984-A) Radiator cap tester adapter	 <p style="margin-top: 10px;">Adapting radiator cap tester to radiator filler neck  <b>a: 28 (1.10) dia.</b>  <b>b: 31.4 (1.236) dia.</b>  <b>c: 41.3 (1.626) dia.</b>                      Unit: mm (in)</p>	NT564
WS39930000 ( — ) Tube presser	 <p style="margin-top: 10px;">Pressing the tube of liquid gasket</p>	NT052

## Cooling Circuit



### System Check

**WARNING:**


Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

#### CHECKING COOLING SYSTEM HOSES

Check hoses for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.

## System Check (Cont'd)

**CHECKING RADIATOR CAP**


To check radiator cap, apply pressure to cap with a tester. NGLC0017S02

**Radiator cap relief pressure:****Standard**

**78 - 98 kPa (0.8 - 1.0 kg/cm<sup>2</sup>, 11 - 14 psi)**

**Limit**

**59 kPa (0.6 kg/cm<sup>2</sup>, 9 psi)**




Pull the negative pressure valve to open it.  
Check that it closes completely when released.

**CHECKING RADIATOR**

Check radiator for mud or clogging. If necessary, clean radiator as follows. NGLC0017S04

**CAUTION:**

- **Be careful not to bend or damage the radiator fins.**
  - **When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, radiator shroud and horns.**
  - **Tape the harness connectors to prevent water from entering.**
1. Apply water by hose to the back side of the radiator core vertically downward.
  2. Apply water again to all radiator core surfaces once per minute.
  3. Stop washing when stains no longer flow out from the radiator.
  4. Blow air into the back side of radiator core vertically downward
  - Use compressed air lower than 490 kPa (5 kg/cm<sup>2</sup>, 71 psi) and keep the air hose end more than 30 cm (11.8 in) away from the core.
  5. Blow air again into all the radiator core surfaces once per minute until no water blows out and the core is dry.



### CHECKING COOLING SYSTEM FOR LEAKS

NGLC0017S03

To check for leakage, apply pressure to the cooling system with a tester.

**Testing pressure: 157 kPa (1.6 kg/cm<sup>2</sup>, 23 psi)**


**CAUTION:**

Higher pressure than specified may cause radiator damage.

GI  
MA  
EM  
LC

### Water Pump REMOVAL

NGLC0018





EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX

**CAUTION:**

- When removing water pump assembly, be careful not to get coolant on timing belt.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.
- To avoid deforming timing cover, make sure there is adequate clearance between it and the hose clamp.


SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## Water Pump (Cont'd)




1. Drain coolant from drain plugs on both sides of cylinder block and radiator. Refer to **MA-28**, "Changing Engine Coolant".

2. Remove radiator hoses (upper and lower) and fan shroud. Refer to "Radiator".
3. Remove drive belts. Refer to **MA-26**, "Checking Drive Belts".
4. Remove water pump pulley.
5. Remove crankshaft pulley and front (upper and lower) belt cover. Refer to **EM-82**, "TIMING BELT".
6. Remove water pump.




## INSPECTION

1. Check for badly rusted or corroded body assembly and vanes. NGLC0019
2. Check for rough operation due to excessive end play.



## INSTALLATION

1. Use a scraper to remove liquid gasket from water pump. NGLC0132
  - Also remove traces of liquid gasket from mating surface of cylinder block.



2. Apply a continuous bead of liquid gasket to mating surface of the water pump.

- Use Genuine Silicone RTV or equivalent. Refer to *GI-50*, "Recommended Chemical Products and Sealants".

When filling the radiator with coolant, refer to *MA-28*, "Changing Engine Coolant".

When installing the drive belts, refer to *MA-26*, "Checking Drive Belts".

GI  
MA  
EM

LC

### Thermostat


#### REMOVAL

NGLC0020

1. Drain engine coolant from drain plugs on radiator.
2. Remove radiator hoses (upper and lower) and fan shroud.
3. Remove drive belts.
4. Remove pulley bracket.
5. Remove water inlet and thermostat assembly.

EC  
FE  
CL

MT



#### INSPECTION

NGLC0021

1. Check valve seating condition at ordinary temperatures. It should seat tightly.

AT  
TF

PD


AX

SU

BR

ST

RS



2. Check valve opening temperature and valve lift.

Description	VG33E	VG33ER
Valve opening temperature	82°C (180°F)	76.5°C (170°F)
Valve lift	More than 10 mm/95°C (0.39 in/203°F)	More than 10 mm/90°C (0.39 in/194°F)



BT  
HA  
SC

3. Then check if valve is closed at 5°C (9°F) below valve opening temperature.

EL

IDX

## Thermostat (Cont'd)



## INSTALLATION

NGLC0022

1. Install thermostat with jiggle valve or air bleeder at upper side.
2. When installing water inlet apply liquid gasket as shown.
  - Use Genuine Silicone RTV or equivalent. Refer to *GI-50*, "Recommended Chemical Products and Sealants".
  - After installation, run engine for a few minutes, and check for leaks.
  - Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

## Radiator


## REMOVAL AND INSTALLATION

NGLC0023

1. Remove under cover.
2. Drain coolant from radiator drain plug.
3. Remove air duct. (From mass air flow sensor to throttle body)
4. Disconnect radiator upper and lower hoses.
5. Remove A/T oil cooler hoses. (A/T model only)
6. Remove radiator lower shroud.
7. Disconnect reservoir tank hose.
8. Remove radiator.
9. After repairing or replacing radiator, install any part removed in reverse order of removal.
10. Refill the engine cooling system. Refer to *MA-28*, "Changing Engine Coolant".
  - After installation, run the engine until it reaches normal operating temperature and check for leaks.

### COMPONENTS

NGLC0024



GI

MA

EM

LC

EC

FE

CL


MT

AT

TF

PD

AX



### INSPECTION

NGLC0028


1. Apply pressure with Tool.  
**Specified pressure value:**  
**157 kPa (1.6 kg/cm<sup>2</sup>, 23 psi)**

SU

BR

ST

RS



2. Check for leakage.

BT


HA

SC

EL

IDX

## Cooling Fan (Crankshaft driven)




## Cooling Fan (Crankshaft driven)

## REMOVAL AND INSTALLATION

NGLC0029


- Do not release the drive belt tension by removing the fan/water pump pulley.
- Fan coupling cannot be disassembled and should be replaced as a unit. If front mark **F** is present, install fan so that side marked **F** faces the front.
- Install the drive belt only after the fan and fan coupling to water pump flange bolts/nuts have been properly torqued.
- Proper alignment of these components is essential. Improper alignment will cause them to wobble and may eventually cause the fan to separate from the water pump causing extensive damage.



## INSPECTION

NGLC0030

Check fan coupling for rough operation, wobbling, oil leakage or bent bimetal fins.



After assembly, verify the fan does not wobble or flap while the engine is running.

**WARNING:**

- When the engine is running, keep hands and clothing away from moving parts such as drive belts and fan.

Refilling Engine Coolant

For details on refilling the engine cooling system, refer to <sup>=NGLC0031</sup> **MA-29**, "REFILLING ENGINE COOLANT".

GI

MA

EM

LC

Overheating Cause Analysis

NGLC0032

		Symptom	Check items			
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	—	—		
		Thermostat stuck closed	—			
		Damaged fins	Dust contamination or paper clogging		—	
			Mechanical damage			
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)			
	Reduced air flow	Cooling fan does not operate	Fan and coupling	—		
		High resistance to fan rotation				
		Damaged fan blades				
		Damaged radiator shroud	—	Fan shroud		
		Improper coolant mixture ratio	—	Coolant quality, viscosity	—	
		Poor coolant quality	—		—	
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp		
				Cracked hose		
			Water pump	Poor sealing		
			Radiator cap	Loose		
Poor sealing						
Radiator			O-ring for damage, deterioration or improper fitting			
		Cracked radiator tank				
		Cracked radiator core				
	Reservoir tank	Cracked reservoir tank				
Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration				
		Cylinder head gasket deterioration				

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# ENGINE COOLING SYSTEM

**VG33E AND VG33ER**

Overheating Cause Analysis (Cont'd)

	Symptom		Check items		
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	Excessive payload	
				Driving in low gear for extended time	
				Driving at extremely high speed	
			Powertrain system malfunction	—	Installed improper size wheels and tires
					Dragging brakes
	Improper ignition timing.				
	Blocked or restricted air flow	Blocked bumper	—	—	
		Blocked radiator grille	Installed car brassiere		
			Mud contamination or paper clogging		
		Blocked radiator	Dirty radiator		
Blocked condenser		Dirty condenser			
Blockage in front of radiator	Installed large fog lamp				

## Service Data and Specifications (SDS)

### THERMOSTAT

NGLC0033

Description	VG33E	VG33ER
Valve opening temperature	82°C (180°F)	76.5°C (170°F)
Valve lift	More than 10 mm/95°C (0.39 in/203°F)	More than 10 mm/90°C (0.39 in/194°F)

### RADIATOR

Unit: kPa (kg/cm<sup>2</sup>, psi) NGLC0034

Cap relief pressure	Standard	78 - 98 (0.8 - 1.0, 11 - 14)
	Limit	59 (0.6, 9)
Leakage test pressure		157 (1.6, 23)